


Menu Map



DMX Values

9CH	Channel	Function	Value	Percent/Setting
	1	Fog	000 010 011 255	No function Fog on
	2	Dimmer	000 255	0-100%
	3	Red	000 255	0-100%
	4	Green	000 255	0-100%
	5	Blue	000 255	0-100%
	6	Amber	000 255	0-100%
	7	Strobe	000 255	0-100%
	8	Auto Color	000 010 011 012 013 015 16 017 019 020 021 023 024 025 027	No function Amber/Blue Amber Amber/Blue dim to bright Green Green/Blue dim to bright Amber/Green Amber/Green/Blue dim to bright Amber/Green Amber/Green/Blue dim to bright

DMX Values (Cont.)

9CH	Channel	Function	Value	Percent/Setting
			028	Amber/Green
			029 031	Amber/Green/Blue dim to bright
			032	Green
			033 035	Green/Blue dim to bright
			036	Amber/Green
			037 039	Amber/Green/Blue dim to bright
			040	Amber/Green
			041 043	Green/Blue dim to bright
			044	Amber/Green
			045 047	Green/Blue dim to bright
			048	Green
			049 051	Green/Blue dim to bright
			052	Amber/Green
			053 055	Amber/Green/Blue dim to bright
			056	Amber/Green
			057 059	Amber/Green/Blue dim to bright
			060	Amber/Green
			061 063	Amber/Green/Blue dim to bright
			064	Red
			065 067	Red/Blue dim to bright
			068	Red/Amber
			069 071	Red/Amber/Blue dim to bright
			072	Red/Amber
			073 075	Red/Amber/Blue dim to bright
			076	Red/Amber
			077 079	Red/Amber/Blue dim to bright
			080	Red/Green
			081 083	Red/Green/Blue dim to bright
			084	Red/Green/Amber
			085 087	Red/Green/Amber/Blue dim to bright
			088	Red/Green/Amber
			089 091	Red/Green/Amber/Blue dim to bright
			092	Red/Green/Amber
			093 095	Red/Green/Amber/Blue dim to bright
			096	Red/Green
			097 099	Red/Green/Blue dim to bright
			100	Red/Green/Amber
			101 103	Red/Green/Amber/Blue dim to bright
			104	Red/Green/Amber
			105 107	Red/Green/Amber/Blue dim to bright
			108	Red/Green/Amber
			109 111	Red/Green/Amber/Blue
			112	Red/Green
			113 115	Red/Green/Blue dim to bright
			116	Red/Green/Amber
			117 119	Red/Green/Amber/Blue dim to bright
			120	Red/Green/Amber
			121 123	Red/Green/Amber/Blue dim to bright
			124	Red/Green/Amber
			125 127	Red/Green/Amber/Blue dim to bright
			128	Red
			129 131	Red/Blue dim to bright
	8	Auto Color		

DMX Values (Cont.)

9CH	Channel	Function	Value	Percent/Setting
			132	Red/Amber
			133 135	Red/Amber/Blue dim to bright
			136	Red/Amber
			137 139	Red/Amber/Blue dim to bright
			140	Red/Amber
			141 143	Red/Amber/Blue dim to bright
			144	Red/Green
			145 147	Red/Amber/Blue dim to bright
			148	Red/Green/Amber
			149 151	Red/Green/Amber/Blue dim to bright
			152	Red/Green/Amber
			153 155	Red/Green/Amber/Blue dim to bright
			156	Red/Green/Amber
			157 159	Red/Green/Amber/Blue dim to bright
			160	Red/Green
			161 163	Red/Green/Blue dim to bright
			164	Red/Green/Amber
			165 167	Red/Green/Amber/Blue dim to bright
			168	Red/Green/Amber
			169 171	Red/Green/Amber/Blue dim to bright
			172	Red/Green/Amber
			173 175	Red/Green/Amber/Blue dim to bright
			176	Red/Green
			177 179	Red/Green/Amber/Blue dim to bright
			180	Red/Green/Amber
	8	Auto Color	181 183	Red/Green/Amber/Blue dim to bright
			184	Red/Green/Amber
			185 187	Red/Green/Amber/Blue dim to bright
			188	Red/Green/Amber
			189 191	Red/Green/Amber/Blue dim to bright
			192	Red
			193 195	Red/Blue dim to bright
			196	Red/Amber
			197 199	Red/Amber/Blue dim to bright
			200	Red/Amber
			201 203	Red/Amber/Blue dim to bright
			204	Red/Amber
			205 207	Red/Amber/Blue dim to bright
			208	Red/Green
			209 211	Red/Green/Blue dim to bright
			212	Red/Green/Amber
			213 215	Red/Amber/Blue dim to bright
			216	Red/Green/Amber
			217 219	Red/Green/Amber/Blue dim to bright
			220	Red/Green/Amber
			221 223	Red/Green/Amber/Blue dim to bright
			224	Red/Green
			225 227	Red/Green/Blue dim to bright
			228	Red/Green/Amber
			229 231	Red/Green/Amber/Blue dim to bright
			232	Red/Green/Amber
			233 235	Red/Green/Amber/Blue dim to bright

DMX Values (Cont.)

9CH	Channel	Function	Value	Percent/Setting
	8	Auto Color	236	Red/Green/Amber
			237 239	Red/Green/Amber/Blue dim to bright
			240	Red/Green
			241 243	Red/Green/Blue dim to bright
			244	Red/Green/Amber
			245 247	Red/Green/Amber/Blue dim to bright
			248	Red/Green/Amber
			249 251	Red/Green/Amber/Blue dim to bright
			252	Red/Green/Amber
			253 255	Red/Green/Amber/Blue dim to bright
	9	Auto Speed	000 255	0–100%